


Overview of the appliance



1.ON/OFF Button	2.Speed Control Button
3.Lamp	4.Battery Release Button
5.Battery	6.Dust Cup
7.Dust Dumping Button	8.Dust Cup Release Button
9.Tube Release Button	10.Tube
11.Floor Brush Release Button	12.Floor Brush
13.Adaptor	14.Crevise Tool
15.Furniture Brush	16.Wall Hanging Clip